# Part Number: PT276-60984

#### **Kit Contents**

Item #	Quantity Reqd.	Description
1	4	Wheel Lock
2	1	Key
3		
4		

### Hardware Bag Contents

Item #	Quantity Reqd.	Description
1		
2		
3		

### **Additional Items Required For Installation**

Item #	Quantity Reqd.	Description
1		
2		
3		

### Conflicts

### **Recommended Tools**

Personal & Vehicle Protection	Notes
None	
Special Tools	Notes
None	
Installation Tools	Notes
Socket	22 mm, Deep Well
Torque Wrench	Dial type or Digital (lbf-ft)
Pliers	With Side Cutter
Special Chemicals	Notes
None	

### **General Applicability**

18" Factory Alloy Wheel 20" Factory or Accessory

### **Recommended Sequence of Application**

Item #	Accessory
1	
2	
3	

\*Mandatory

**NOTE:** Part number of this accessory may not be the same as the part number shown.

### Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		
2		
3		

## Legend

STOP	<b><u>STOP</u></b> : Damage to the vehicle may occur. Do not proceed until process has been complied with.
	<b>OPERATOR SAFETY:</b> Use caution to avoid risk of
	injury.
	<b><u>CAUTION</u></b> : A process that must be carefully observed
<u>/:\</u>	in order to reduce the risk of damage to the
	accessory/vehicle and to ensure a quality installation.
est -	TOOLS & EQUIPMENT: Used in Figures calls out the
3	specific tools and equipment recommended for this
	process.
	<b>REVISION MARK:</b> This mark highlights a change in
	installation with respect to previous issue.

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.



# 1. Remove One Lug Nut

(a) Carefully remove one lug nut from each wheel. Avoid damage to wheel.

### 2. Install Wheel Lock

- (a) By hand, install a Wheel Lock on each wheel.
- (b) Take the key supplied in the wheel lock set. Place it on top of the wheel lock and turn until the patterns engage.
- (c) Place the socket on top of the key. Using a torque wrench and while applying pressure on the key tighten the wheel locks to 131 N-m (97 lbf-ft).

# 3. Key Storage

- (a) Attach the key to the vehicle lug wrench using the cable tie. (Fig. 3-1)
- (b) Pull cable tie tight with pliers and cut off excess with side cutters.
- (c) Place the lug wrench with the key attached in the lug wrench storage area. (See Fig. 3-1).

# 4. Complete the Installation



Verify part number on package Wheel locks have been installed at a torque of 131 N-m (97 lbf-ft). Verify process only – Check torque during installation No damage to wheel.
of 131 N-m (97 lbf-ft). Verify process onl – Check torque during installation
- Check torque during installation
No damage to wheel.