Part #: PT398-47090

NOTE: Part number of this accessory may not be the same as the part number shown.

Conflicts:

Do not install into Manual Transmission Vehicles or Vehicles without RKE systems.


Kit Contents


PREPARATION

GBS ECU

















Status Monitor











Additional Items

(may be required)

Item#	Description

Recommended Sequence of Application

Item#	Description
1	TVIP V5 RS3200 plus
2	TVIP V4 Remote Engine Starter

Recommended Tools

Personal & Vehicle Protection	Description
Safety Glasses	
Safety Gloves	(Optional)
Vehicle Protection	Blankets, Parts Boxes
Special Tools	
Techstream	Version 4.1 or later
Striker Tool	
Installation Tools	
Screwdriver	#2 Phillips, Flat Blade Jeweler's
Nylon Panel Removal Tool	e.g. Panel Pry Tool #1 Toyota SST# 00002-06001-01
Side Cutters	
Torque Wrench	48 in•lbf (5.4 N•m)
Таре	Clear, Electrical
Socket	10mm, extension
Special Chemicals	
Cleaner	VDC Approved Cleaner
Glass Cleaner	Household Glass Cleaner

Issue: D 05/22/09 Page 1 of 35

Table of Contents

I.	Preparation	1–4
	1. Table of Contents	2
	2. Wire Routing Overview	
II.	Procedure	5-27
	1. Hood Switch Installation	5
	2. Disassembly (Driver's Side)	g
	3. GBS ECU Preparation	10
	4. V5 Wire Harness Installation (Driver's J/B Area)	
	5. V5 Wire Harness Installation (Driver's Cowl Area)	16
	6. Registration Preparation	22
	7. Registration	24
	8. Labels	27
	9. Completing the Installation	27
III.	Checklist	28-32
	Accessory Function Checks	28
	2. Vehicle Function Checks	
I\/	Addendum I	33-35

Legend



Do not proceed until process has been completed.



Follow steps carefully to avoid damaging the Vehicle or Accessory



Use caution to avoid injury.



Used in Figures to call attention to specific tools recommended for the process.



Highlights a change in installation with respect to previous issue.



Indicates that torque is related to safety.



Video available; click to play.

Accessory Installation Practice (read before installation)


Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.)
- · Safety (eye protection, checking torque procedure, etc.)
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.)
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.)

Please see your Toyota dealer for a copy of this document.



PRIUS



1	Rear Board		
2	Rear Box		
3	Rear Trim		
4	DS Step Cover		
5	DS Cowl Cover		
6	Lower Dash Cover		
7	Lower Steering Column Cover		
	Disconnect all Corresponding Connectors.		

1. Hood Switch Installation.

- a. Place the Vehicle in Park with the Parking Brake set.
- b. Remove the Rear Board.

Issue: D 05/22/09 Page 5 of 35

c. Remove the Rear Box.

d. Remove the Rear Trims to gain access to the Battery.

- e. Disconnect the Negative Battery Terminal.
 - Note the Battery Cable Position as it will be re-installed in the same position.




CAUTION: Do not touch the Positive Terminal.

f. Swap the Bolt and Nut on the Negative Battery Terminal from one side to the other for easier installation.

Issue: D 05/22/09 Page 6 of 35

Check if Hood Switch is installed



Hood Switch

(Go to Next Section on Page 9)

Issue: D 05/22/09 Page 7 of 35

- h. Remove the tape securing Hood Switch Pre-Connector.
- Connect the Jumper Connector.

j. Use 1 Wire Tie to secure the Hood Switch Connectors.

Issue: D 05/22/09 Page 8 of 35

a. Remove the Driver's Side Step Cover.

- b. Remove the Driver's Side Cowl Cover.
 - · Remove 1 Nut.

- c. Remove the Lower Dash Cover.
 - Remove 1 Screw.
- d. Wrap the Lower Dash Cover in a blanket and place on the floor.

Issue: D 05/22/09 Page 9 of 35

e. Dislodge the Steering Column's Center Clip.



CAUTION: Do not force this clip as it is very easy to break.

- f. Release the Back Clips on both sides.
- g. Release the Front Clips on both sides.
 - Turn the Steering wheel from Right to Left to access the Holes.
 - Use a Flat Blade Jeweler's Screwdriver wrapped with Electrical Tape to release the clips.

3. GBS ECU Preparation.

V5/V4 ADD-ON ONLY

- a. Dislodge the RES ECU and GBS Bracket.
 - · Remove 1 Bolt and Washer.



CAUTION: Do not drop the Bolt and Washer.

- b. Disconnect RES Connector.
- c. Discard the GBS Bracket.

Issue: D 05/22/09 Page 10 of 35

d. Install the GBS Bracket from the Kit to the GBS ECU.

e. Attach 1/2 Piece of Foam Tape to GBS ECU.

f. Set the GBS sensitivity value to "5".

A _[

Issue: D 05/22/09 Page 11 of 35

4. V5 Wire Harness Installation. (Driver's J/B Area)

Disconnect the Vehicle
 Connectors on the right side of the Junction Box.

- b. Disconnect the 36P Vehicle Connector.
 - · Release Black Connector Lever.

 Using a Flat Blade Jeweler's Screwdriver remove the Connector's Black Lever.



CAUTION: Do not force the Lever.

d. Lift up the Terminal Retainer Clip.



CAUTION: Do not pull out the Retainer.

Issue: D 05/22/09 Page 12 of 35



- e. Insert the V5 Green Wire Terminal into the indicated location on the 36P Vehicle Connector.
 - Close the Terminal Retainer Clip.



VERIFY: Terminal Pins are properly inserted and do not come out.

- f. Re-attach the Connector's Black Lever.
- g. Reconnect the Vehicle Connectors.

Issue: D 05/22/09 Page 13 of 35

V5 ONLY

h. Install GBS ECU using the Bolt and Washer from the Kit.



CAUTION: Do not drop the Bolt and Washer.

Issue: D 05/22/09 Page 14 of 35

V5/V4 ADD ON ONLY

- Attach RES Bracket to the GBS Bracket.
- j. Install the GBS ECU with RES Bracket using the Bolt and Washer from the Kit.



CAUTION: Do not drop the Bolt and Washer.

k. Connect the V4 24P Connector to the RES ECU.

- I. Connect the V5 8P Connector to the GBS ECU.
- m. Secure the V5 Harness to Vehicle Harness with 2 Wire Ties.
- n. Secure the V5 5P BLACK Connector as shown using 1 Wire Tie.

Issue: D 05/22/09 Page 15 of 35

- o. Dislodge the Vehicle's Harness Shielding.
 - · Release 1 Clip.
- p. Route the V5 Harness along the Vehicle Harness towards the Driver's Cowl Area.
- q. Reinstall the Vehicle's Harness Shielding.
- Secure the V5 Harness to Vehicle Harness Shielding with 1 Wire Tie.

5. V5 Wire Harness Installation. (Driver's Cowl Area)

a. Secure V5 Harness to Vehicle Harness with 1 Wire Tie.

V5 ONLY

 Connect the V5 3P Connector to the Vehicle's 3P Pre-Connector.

Issue: D 05/22/09 Page 16 of 35

c. Use 2 Wire Ties to secure the V5 3P Connectors as shown.

d. Disconnect the Vehicle's White 12P Connector.

e. Plug the V5 12P Connectors in between the Vehicle's Connectors.

Issue: D 05/22/09 Page 17 of 35

f. Disconnect the Vehicle's 26P Connector.

 g. Plug the V5 26P Connectors in between the Vehicle's Connectors.

- h. Use 1 Wire Tie to secure the V5 26P Connectors to the Vehicle Harness.
- i. Use 1 Wire Tie to secure the V5 12P Connector to the Vehicle Harness.

Issue: D 05/22/09 Page 18 of 35

V5/V4 ADD-ON ONLY

Cut 2 Wire Ties securing the V4 Harness.

- k. Disconnect the V4's and Vehicle's 3P Connectors.
- Connect the V5 3P Connectors in between the V4's and the Vehicle's 3P Connectors.

m. Disconnect the Vehicle's and V4's 12P Connectors.

Issue: D 05/22/09 Page 19 of 35

n. Plug the V5 12P Connectors in between the V4's and the Vehicle's Connectors.

o. Disconnect the Vehicle's and V4's 26P Connectors.

 Plug the V5 26P Connectors in between the V4's and the Vehicle's Connectors.

Issue: D 05/22/09 Page 20 of 35

q. Apply 1 Piece of Foam Tape to the metal edge of the opening above the Driver's Cowl Connector Block.

- Secure the V4 26P Connector to the Vehicle's Harness with 1 Wire Tie.
 - You may need to pull some of the Vehicle Harness out of the Pillar. DON'T FORCE THE HARNESS.
- s. Push the V4 26P Connector and Vehicle Harness back into the opening in the Pillar.

- Secure the V5 26P Connector to the Vehicle's Harness with 1 Wire Tie.
- Secure the V4 and V5 12P
 Connectors to the Vehicle's
 Harness with 1 Wire Tie.

Issue: D 05/22/09 Page 21 of 35

6. Registration Preparation.

- Using VDC approved cleaner and cleaning method, clean the area indicated on the Lower Dash Cover.
- b. Attach 2 Foam Tapes as shown.
- c. Replace Knockout Panel with the V5 Status Monitor.

- d. Connect the V5 4P Connector to the V5 Status Monitor.
- e. Reinstall the Lower Dash Cover.
 - Reconnect the Vehicle's Connectors.

Icone: D (

Issue: D 05/22/09 Page 22 of 35

f. Reassemble the Vehicle.



Note: Make sure that all Connectors are reconnected.



Note: Verify that panels fit together properly, with no uneven gaps.


- g. Verify that the Short Pin is Installed.
 - · If not Install now.

h. Temporarily reconnect the Negative Battery Cable.

CAUTION: Do not touch the Positive Terminal.


Issue: D 05/22/09 Page 23 of 35

PRIUS




7. Registration.

- a. Connect the Techstream Notebook to the Vehicle's Diagnostic Port.
- b. With the Smart Key in your possession, press the Power Button twice to select the Ignition "ON" position.




- Start the TIS Techstream Application by clicking on the shortcut located on the Desktop.
- d. Click "Connect to Vehicle."




- Confirm that the information displayed on the Vehicle Connection Wizard is correct for the vehicle. If not, verify that the Techstream is properly connected.
- Select w/Smart Key.
- g. Click "Next>."

Issue: D 05/22/09

Page 24 of 35



- h. Click "Customize Setting."
 - . Click



- Make sure that the "Customize" tab is selected.
- k. Select "Option Setup."
- l. Click


NOTE: If no "Option Setup" ONLY


If during this step you do not

If during this step you do not see "Option Setup" as an option, please proceed to Addendum I (pg. 33).

- m. Select "ON."
- n. Click

Issue: D 05/22/09 Page 25 of 35







p. Click

The Customize Select Customize Function [Viveless Door Lock Security Viveless Door Lock Security Viveless Door Lock Security Viveless Delect Customize Farameter for English Security System OFF Remarkable Company C	Select Customize Function Viviens Coor Lock	Select Customize Function Vivolence Chart Lock
omize Function Lock Select Customize Farameter HEM	omize Function Lock Door Lock Posts Winds Select Customize Farameter	omize Function Lock Door Lock Power Window Select Customize Farameter FEM SETTING
	Front Work	Form Window
	Fores West	Form Window

q. Click "Close."




Issue: D 05/22/09 Page 26 of 35





8. Labels.

- Use Household Glass
 Cleaner to clean the inside of the Front Door Windows.
- b. Use a piece of Clear Tape to lift the Label off its protective backing.



c. Attach the Label as shown.



NOTE: Make sure to Align according to Etching or Other Label.

REPEAT: steps a—c with the other Window.

9. Completing the Installation.

 Position the Negative Battery Cable at the original factory position.



• Tighten the Nut to 48 in•lbf (5.4 N•m).



CAUTION: Do not touch the Positive Terminal.

- b. Finish reassembling the Vehicle.
- **VERIFY:** That panels fit together properly, with no uneven gaps.
 - **VERIFY:** That all Connectors are plugged in.
 - c. Clean up and Remove trash.
 - Sealed in its protective bag, place the Owner's Manual in the Glove box.
 - e. Reset the power windows.
 - · Turn the ignition "ON."
 - · Lower the Windows halfway.
 - Pull up on the Power Window Switches until the windows close.
 - Continue to hold up on the switches for a minimum of 1 Second.

Accessory Function Checks

	Procedure	Look for:
1	Press and release the remote control's lock but-	The turn signal lights flash once
	ton to start the system's arming process.	All doors lock.
		The Security LED lights up.
2	Wait 30 seconds.	Security LED stops flashing; the system is now armed.
3	Press and release the remote control's unlock button to disarm the system.	The turn signal lights flash twice. The driver's door unlocks. The Security LED flashing.

Open the driver's door, with the smart key in your possession, press the power button to "ON". Roll down all the windows, remove the key and exit the vehicle.

4	Arm and disarm the system with the remote again, then wait 60 seconds.	The doors automatically re-lock. The system automatically starts the arming process.
5	Press and release the remote control's unlock button again to stop the arming process.	Refer to step 3.
6	Press the lock button on the driver's exterior door handle to start the arming process.	All doors lock. The Security LED lights up.
7	Wait 30 seconds.	Security LED stops flashing; the system is now armed.
8	Reach inside and manually unlock the driver's door to trigger an alarm.	The driver's door automatically re-locks. The horn sounds repeatedly. The headlights flash repeatedly. The turn signal lights flash repeatedly. The Security LED lights up.
9	Manually unlock the driver's door again and hold it unlocked, open the door, then sit in the driver's seat.	The driver's door lock attempts to lock repeatedly. The horn continues to sound repeatedly. The headlights and turn signal lights continue flashing. The Security LED remains on.
10	The smart key in your possession, press the power button twice on the dash to "START" to stop the alarm.	The horn stops sounding. All the lights stop flashing and/or turn off. The Security LED turns off. The starter cranks and the engine starts.

Issue: D 05/22/09

TVIP V5 RS3200 PLUS

Press the "START" button to turn the vehicle off, and then exit the vehicle.

	T	7
11	With the door open, press the lock switch on the door to lock the doors, then close the door to start the system's arming process.	All doors lock. The Security LED lights up.
12	Wait 30 seconds.	SECURITY LED stops flashing; the system is now armed.
13	Reach inside and manually unlock the front passenger's door to trigger an alarm.	The front passenger's door automatically re-locks. The horn sounds repeatedly. The headlights flash repeatedly. The turn signal lights flash repeatedly. The SECURITY LED lights up.
14	Press and release the remote control's unlock button to stop the alarm.	The horn stops sounding. All the lights stop flashing. The Security LED flashing.
15	Press and release the remote control's lock button to start the system's arming process, then wait 30 seconds until the system is armed.	Refer to steps 1 and 2.
16	Unlock and open one of the rear passenger doors to trigger an alarm. (if available).	Refer to step 13.
17	Press and release the remote control's unlock button to stop the alarm.	Refer to Step 14
18	Repeat the above steps with the other rear passenger door. (if available).	Refer to steps 1, 2, and 13.

Roll up all windows, remove the key and exit the vehicle.



Take the Smart Key and the Smart Card Key away from the Vehicle. Place them 7ft. (2 meters) or more away from the Vehicle.

19	Press and release the remote control's lock button to start the arming process.	Refer to step 1.
20	Wait 30 seconds.	After 30 seconds, the Security LED stops flashing; the system is now armed.

Issue: D 05/22/09 Page 29 of 35

Perform the following check in a temperature-controlled environment. (50°-90° F)

21	With the tip of a key, or Striker Tool pulled all the way out (PPO only), tap the center of the driver's door window to trigger the alarm.	The horn sounds repeatedly. The headlights flash repeatedly. The turn signal lights flash repeatedly. The Security LED lights up.
22	Press and release the remote control's unlock button to stop the alarm.	Refer to Step 14



NOTE: If the alarm does not trigger during functional verifications, the Smart Key and Smart Card Key might be too close. Move them farther away from the vehicle and test the system again.

NOTE: If the alarm does not trigger during functional verifications, increase the GBS sensitivity to the next setting.

NOTE: If you do not disarm the system, the alarm will last 20 seconds. It is not necessary to check the alarm duration.

A

Issue: D 05/22/09 Page 30 of 35


2010-

Vehicle Function Checks


Function	Function
Head Lights	ABS Light (if equipped) If the warning light remains on, it may indicate a system malfunction.
High Beams	Rear Wiper/Washer (if equipped)
Turn Signal Lights	Clock (if equipped)
Tail Lights	Accessory Power Socket (if equipped)
Stop Lights	Starter
Backup Lights	Audio/Video (if equipped)
Hazard Lights	Power Sliding Door (if equipped)
Marker Lights	Convenience Memory Settings (if equipped)
Dome/Courtesy Lights	Heated Seats (if equipped)
Panel/Switch Illumination	Massage Seats (if equipped)
Accessory Controls/Illumination (if equipped)	Rear Window Defogger (if equipped)
Key Sensor Buzzer	Power Side Mirrors (if equipped)
Fog Lights (if equipped)	Side Mirror Defogger (if equipped)
Daytime Running Lights (if equipped)	Front Windshield Defogger (if equipped)
Trunk/Tailgate/Bed Lights (if equipped)	Navigation System (if equipped)
Glove Box Light (if equipped)	Rear Sunshade (if equipped)
Cruise Control Light (if equipped)	Steering Wheel Audio Control (if equipped)
Seat Belt Warning Light If the warning light remains on, it may indicate a system malfunction.	Steering Wheel Column Adjusts Without Interference

Issue: D 05/22/09 Page 31 of 35

Function	Function
Air Bag Warning Light If the warning light remains on, it may indicate a system malfunction.	Lamp Failure Sensor If the warning light remains on, it may indicate a system malfunction.
Track/Skid Control Light (if equipped) If the warning light remains on, it may indicate a system malfunction.	Front Wiper/Washer
HVAC	Hood Latch Release
Power Locks (if equipped)	Passenger Air Bag Switch (if equipped)
Power Windows (if equipped)	Rollover Side Curtain Air Bag Switch (RSCA) (if equipped)
Power Seats (if equipped)	Tire Pressure Monitoring System (TPMS).
Power Moon/Sun Roof (if equipped)	Prior to TPMS activation and Pre-delivery Service (PDS) of the Vehicle the TPMS light will blink when IG is turned on.
Horn	After TPMS activation and PDS of the Vehicle the TPMS light will illuminate for a few seconds and go off
Gauges	when IG is turned on.
Remote Air Conditioning system	




Issue: D 05/22/09




| 1. Alternative Registration.

For Vehicles that did not have an "Option Setup" during normal Registration.

- Connect the Techstream Notebook to the Vehicle's Diagnostic Port.
- b. With the Remote Control Key in your possession, press the Start Button to select either "OFF" or the "ACC" position.



- Start the TIS Techstream Application by clicking on the shortcut located on the Desktop.
- d. Click "Connect to Vehicle."




- e. Select "Toyota" for the Division.
- f. Select "Prius" for the Model.
- g. Select "2009" for the Model Year.


CAUTION: You must select 2009.

- h. Select w/Smart Key.
- Make additional selection based on the Vehicle Specifications.
- j. Click "Next>."


Issue: D 05/22/09 Page 33 of 35



- k. Click "Customize Setting."
 - . Click




- m. Make sure that the "Customize" tab is selected.
- n. Select "Option Setup."
- o. Click




- p. Select "ON."
- q. Click

Issue: D 05/22/09 Page 34 of 35



r. Click "Next" to accept the changes to the Vehicle.



s. Click

t. Click "Close."

Go To Section 8 (Pg. 27)

Issue: D 05/22/09

Page 35 of 35