Toyota Rav4 2014 **Splash Guards**

Business Partner: L31

Part Number: 00016-42028 (4 Piece Set)

00016-42029 (Rears Only)

Accessory Code: MG40 (4 Piece Set)

MG20 (Rears Only)



Conflicts

Any running board will interfere with front Splash Guard

Kt Contents

| Item# | Quantity Reqd. | Description |
|-------|----------------|---------------------|
| 1 | 2 | Front Splash Guards |
| 2 | 2 | Rear Splash Guards |
| 3 | 1 | Hardware Bag |

Hardware Bag Contents

| Item# | Quantity Reqd. | Description | | | | |
|-------------|----------------|-------------------------|--|--|--|--|
| 4 Piece Set | | | | | | |
| 1 | 4 | Clips | | | | |
| 2 | 6 | Screw, M6-3 x 20mm Hex | | | | |
| 3 | 6 | Screw, #8 x 3/4 Panhead | | | | |
| 4 | 2 | Push Retainers | | | | |
| Rears O | nly | | | | | |
| 1 | 4 | Clips | | | | |
| 2 | 6 | Screw, #8 x 3/4 Panhead | | | | |

Additional Items Required For Installation

| Item # | Quantity Reqd. | Description |
|--------|----------------|-------------|
| | | |

Recommended Took

| Safety Tools | |
|---------------------------|-------------------------|
| Safety Glasses | |
| Special Tools | |
| Magnetic Fishing Tool | |
| Protective Blanket | |
| Installation Tools | |
| Wiping Cloth | Non-Scratch, Lint Free |
| Screwdriver | #2 Phillips |
| Socket | 10mm (3/8") |
| Air Rachet | |
| Guide Awl Tool | |
| | |
| Special Chemicals | |
| Cleaner | Isopropyl Alcohol-Based |
| | Water 50:50 |
| | |

Color Applicability/ TrimLevel

| Accessory | | | | |
|--------------------|--|--|--|--|
| Vehicle/Trim Color | | | | |
| N/A | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

General Applicability

Note: RAV4 Models 2014

Recommended Sequence of Application

| Item# | Accessory | |
|-------|---------------|--|
| 1 | Splash Guards | |
| | | |

Legend



STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.



OPERATOR SAFETY: Use caution to avoid risk of injury.



CAUTION: A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.



TOOLS & EQUIPMENT: Used in Figures calls out the specific tools and equipment recommended for this



REVISION MARK: This mark highlights a change in installation with respect to previous issue.

SAFETY TORQUE: This mark indicates that torque is related to safety.

SPECIAL NOTE:

After TMS and Safety mandated preparatory steps have been taken, the installation sequence is the suggested method for completing the accessory installation. In some instances the suggested sequence is written for one associate to install and in others the sequence is given as part of a team accessory installation. Unless otherwise stated in the document, the associates may perform the installation steps in any order to make the installation as efficient as possible while maintaining consistent quality.



Care must be taken while installing this accessory to ensure damage does not occur to the vehicle. Use approved guidelines to insure a quality installation.

These guidelines can be found in the 'Accessory Installation Practices' document.



A. InstallationPreparation

- 1. Verify that the part is for the correct vehicle model and that it fits the vehicle properly.
- 2. Inspect the vehicle for damage prior to installing the Splash Guards.
- 3. Make sure that all vehicle installation surfaces are free of dirt and/or grease.
- 4. Turn steering wheel fully to left and lock.



NOTE: If vehicle has a running board skip to Step D



B. Clean Front Mounting Area

1. Clean front body panel where splash guard is to be located with a clean cloth. (Fig. 1)



C. Installation

- Install provided Push Retainer into bottom of Splash Guard and into Factory hole as indicated. (Fig. 2)
- 2. Mount Splash Guard on body panel and install supplied M6 Screws in locations indicated while holding part up and into body panel then tighten. (Fig. 3)
- 3. Repeat process for other side.











D. Clean Rear Mounting Area

1. Clean rear body panel where splash guard is to be located with a clean cloth. (Fig. 4).



E. Installation of Rear Splash Guard

- Remove two factory screws where indicated. DO NOT DISCARD HEX FASTENER FROM BOTTOM LOCATION. (Fig. 5)
- 2. Install supplied Spring Clips over panel edge at dimple locations. (Fig. 6)
- 3. Place Splash Guard on vehicle. Loose start the supplied panhead center fasterner to hold the part. (Fig. 7).
- 4. Use guide awl tool to the bottom fastener location, and then install the original factory hex fastener. (Fig. 8)
- 5. Install the supplied panhead upper fastener, tighten the center fastener, and then install the supplied panhead lower fastener. (Fig. 7)
- 6. Repeat process for other side.











| Charles | Look Fore |
|---|---|
| Check: | <u>Look For:</u> |
| Accessory Function Check | |
| VisualAlignment | Splash Guards should lay flush against vehicle. |
| | |
| Gaps between spoiler and trunk lid | No more than a 1mm gap is allowed between the |
| | part and the vehicle. |
| | |
| | |
| | |
| Vehicle Appearance Check: | |
| | |
| After accessory installation and rem oval of pro- | Ensure no damage (including scuffs & scratches) |
| tective covers, perform a visual inspection | was caused during the installation process. |
| | (For PPO installations, refer to TMS Accessory |
| | Quality Shipping Standard) |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |