



**ROSTRA REARSIGHT  
250-8308  
INSTALLATION INSTRUCTIONS**



**SERVICE PARTS**

ITEM	QTY	PART NUMBER	DESCRIPTION	CONTENTS
1	1	250-8208	MONITOR ASSEMBLY	MONITOR, MONITOR POWER HARNESS, ADAPTER HARNESS, WINDSHIELD LUG
2	1	250-8117	CAMERA ASSEMBLY	CAMERA, CAMERA EXTENSION HARNESS
3	1	250-8535	SACK PART ASSEMBLY	INLINE CONNECTORS, MIRROR LUG GLUE, FOAM TAPE, WIRE TIES, ALCOHOL PADS
4	1	250-8536	LICENSE PLATE BRACKET	LICENSE PLATE BRACKET

# INSTALLATION

## 1. MOUNTING THE MIRROR MONITOR

- A. IF NO LUG EXISTS, FOLLOW THE INSTRUCTIONS ON THE **GLUE PACKAGE** FOUND IN THE **SACK PART** AND ATTACH PROVIDED LUG TO WINDSHIELD.
- B. REMOVE CURRENT MIRROR AND VERIFY MOUNTING LUG IS THE SAME AS THE ONE IN THE MOUNTING STEM OF THE MONITOR.
- C. MOUNT MIRROR AND TIGHTEN **PHILLIPS HEAD SCREW** TO FIX MONITOR STEM TO THE LUG.

## 2. MONITOR POWER HARNESS MUST BE ROUTED AND KEPT CLEAR OF AIRBAGS AND/OR VEHICLE WIRING AND ANTENNAS.

**NOTE: FAILURE TO ROUTE HARNESS PROPERLY, MAY IMPEDE PROPER FUNCTION OF ACCESSORY AND/OR CAR FEATURE.**

CONNECT HARNESSES AS SHOWN IN KIT CONTENTS DIAGRAM ON **PAGE 1**.

## 3. THE **CCD ADAPTER HARNESS** IS USED TO CONVERT THE MONITOR FOR USE WITH **CCD CAMERAS**. IT MAY BE USED IN CONJUNCTION WITH THE **30FT CAMERA EXTENSION HARNESS** OR CONNECTED DIRECTLY TO THE CAMERA USING THE PROVIDED LINK. CONNECT **ADAPTER HARNESS** TO **VIDEO ONE** FOR USE IN THE REVERSE CAMERA APPLICATION.

## 4. THE **CAMERA ASSEMBLY** IS FITTED WITH A **SHROUD** WHICH ALLOWS MOUNTING TO THE **LICENSE PLATE BRACKET (SEE FIGURE 1)**, UNDER THE LIP OF THE REAR GATE OR WHERE A HORIZONTAL SURFACE IS APPROPRIATE (**SEE FIGURE 2**). YOU MUST CLEAN THE AREA THOROUGHLY WITH THE PROVIDED ALCOHOL PAD, LET DRY, THEN APPLY DIRECT PRESSURE FOR **30 SECONDS** TO ENSURE PROPER ADHESION.

## 5. THE **30FT CAMERA EXTENSION HARNESS** IS ONLY USED WHEN EXTRA LENGTH IS NEEDED OR WHEN A CAMERA CONNECTION IS OUTSIDE THE VEHICLE AND A **WATER-PROOF CONNECTION** IS REQUIRED.

## 6. UTILIZE THE **3 INLINE CONNECTORS** TO TIE THE **RED WIRE** TO **ACCESSORY POWER**, THE **GREEN WIRE** TO **REVERSE LIGHT POWER** AND THE **BLACK WIRE** TO **GROUND**.

## 7. SEE **FIGURE 1** FOR ORIENTATION OF THE LICENSE PLATE BRACKET.

## 8. SEE **FORM #5086** FOR CONVERSION OF SHROUD FOR SHOWN DRILL MOUNT. **SEE FIGURE 3**



**FIGURE 1**



**FIGURE 2**



**FIGURE 3**