

Part Number: PTR35-00070
PTR35-00110

NOTE: Part number of this accessory may not be the same as the part number shown.

Kit Contents

Item #	Quantity Req'd.	Description
1	1	Oil Filler Cap w/gasket
2	1	TRD Appliqué
3	1	Instructions
4	1	SAE Oil Decal

Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Req'd.	Description
1		
2		
3		

Additional Items Required For Installation

Item #	Quantity Req'd.	Description
1		
2		
3		

Conflicts

None

Recommended Tools

Personal & Vehicle Protection	Notes
Blankets or covers	
Special Tools	Notes
Installation Tools	Notes
Special Chemicals	Notes
Liquid Dish Soap/Water Solution	Joy brand or similar
Distilled Water	

General Applicability






All Toyota and Scion models with screw-in style oil cap

Recommended Sequence of Application

Item #	Accessory
1	
2	
3	

*Mandatory

Legend

	STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.
	OPERATOR SAFETY: Use caution to avoid risk of injury.
	CAUTION: A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.
	TOOLS & EQUIPMENT: Used in Figures calls out the specific tools and equipment recommended for this process.
	REVISION MARK: This mark highlights a change in installation with respect to previous issue.

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.



1. Check Box Contents

- (a) Check box for contents and/or damage.

2. Vehicle Protection

- (a) Open vehicle hood.
- (b) Use blankets to protect the front grille area.



3. Removal Procedure: Factory Oil Filler Cap

- (a) Remove factory oil filler cap by turning cap counter-clockwise (Fig. 3-1).

Note: Yaris oil filler cap shown. Other vehicle models may have oil cap in a different area on the engine.

- (b) Discard factory oil filler cap.



Fig. 3-1

4. Installation Procedure: TRD Oil Filler Cap

- (a) Remove TRD appliqué from the top of the oil filler cap by lifting the piece of tape that secures the appliqué (Fig. 4-1).

- (b) Do not touch top of oil filler cap.



Fig. 4-1



Fig. 4-2

- (c) Install TRD oil filler cap by turning clockwise until cap is snug on the engine (Fig. 4-2).



Fig. 4-3

- (d) If necessary, the top of the oil filler cap may be cleaned by using a lint-free cloth and a solution of 4 drops Joy liquid dish soap per cup of water (Fig. 4-3).
- (e) Use another lint-free cloth and distilled water to wipe top of oil filler cap (Fig. 4-3).
- (f) Dry top of oil filler cap with a lint-free cloth.



Fig. 4-4

- (g) Remove liner paper from back of TRD appliqué to expose adhesive (Fig. 4-4).



- ⚠ (h) Install TRD appliqué on oil filler cap with TRD logo facing forward (Fig. 4-5).
 - (1) The TRD logo is correct if it can be read while standing in front of the vehicle.
 - (2) Press logo firmly over entire surface to fully seat adhesive.



- ⚠ (i) Carefully remove the plastic laminate from the top of the TRD appliqué (Fig. 4-6).
 - (j) Remove vehicle protection from front of vehicle.
 - (k) Check the Owner's Manual to determine the correct oil
 - (l) Check the Owner's Manual to determine the correct oil Viscosity for the vehicle the TRD Oil Cap has been installed.
 - (m) Place the foil label on a paper pad and using a ball point pen, write the oil viscosity on the label.
 - (n) Find a suitable location in the engine compartment where the label will be readily visible and clean this surface.
 - (o) The label will be correct if it can be read while standing in front of the vehicle.
 - (p) Peel the liner off the back of the label and affix the label to the cleaned surface.

Checklist - these points **MUST** be checked to ensure a quality installation.

<u>Check:</u>	<u>Look For:</u>
<u>Accessory Function Checks</u>	
<input type="checkbox"/> Correct TRD logo clocking	TRD logo can be read from front of vehicle
<input type="checkbox"/> TRD appliqué finish	No plastic laminate covering TRD appliqué
<input type="checkbox"/>	
<u>Vehicle Function Checks</u>	
<input type="checkbox"/>	
<input type="checkbox"/>	