

Section I – Installation Preparation

**Part Number: PTR43-00085**

**Kit Contents**

| Item # | Quantity Req'd. | Description            |
|--------|-----------------|------------------------|
| 1      | 1               | Performance Air Filter |
| 2      | 1               | Warning Label          |

**Additional Items Required For Installation**

| Item # | Quantity Req'd. | Description |
|--------|-----------------|-------------|
| 1      |                 |             |

**Conflicts**

| PPO Code | Description |
|----------|-------------|
| None     | N/A         |

**Recommended Tools**

|                           |                            |
|---------------------------|----------------------------|
| <b>Safety Tools</b>       |                            |
| Safety Glasses            | or Goggles                 |
| <b>Special Tools</b>      |                            |
| Vehicle Protection        | Blankets                   |
| <b>Installation Tools</b> |                            |
| None                      |                            |
| <b>Special Chemicals</b>  |                            |
| Toyota Approved Cleaner   | Prep Solvent 70 or similar |

**General Applicability**

|                                |
|--------------------------------|
| Scion tC – 2.4L I4 → 2005-2010 |
| Corolla – 1.8L I4 → 2003-2008  |
| Matrix – 1.8L I4 → 2003-2008   |

**Color Applicability/Trim Level**






| Accessory Color    |     |  |  |  |  |  |  |  |  |  |  |  |  |  |
|--------------------|-----|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Vehicle/Trim Color | N/A |  |  |  |  |  |  |  |  |  |  |  |  |  |
| N/A                |     |  |  |  |  |  |  |  |  |  |  |  |  |  |

**Recommended Sequence of Application**

| Item # | PPO Code | Accessory |
|--------|----------|-----------|
|        | None     | N/A       |

\*Mandatory


**Legend**

|   |   |
|---|---|
|  | <b>STOP:</b> Damage to the vehicle may occur. Do not proceed until process has been complied with.  |
|  | <b>OPERATOR SAFETY:</b> Use caution to avoid risk of injury   |
|  | <b>CRITICAL PROCESS:</b> Proceed with caution to ensure a quality installation. These points will be audited on a completed vehicle installation            |
|  | <b>GENERAL PROCESS:</b> This highlights specific processes to ensure a quality installation. These points will be audited during the accessory installation |
|  | <b>TOOLS &amp; EQUIPMENT:</b> This calls out the specific tools and equipment required for this process   |


**A. Check Box Contents**



1. Check box for contents and/or damage.

**B. Vehicle Preparation**






-  1. Use blankets to protect the front grille and passenger-side front fender area.


**C. Removal Procedure: OE Air Filter**

1. Remove the original equipment (OE) air filter.
  - i. Unlatch the two air filter housing clips. (Fig. 1)
  -  ii. Move the air filter housing lid away from the engine and upward to expose air filter.
  - iii. Remove OE air filter from air filter housing lid and discard the filter. (Fig.2)



**D. Installation Procedure: TRD Air Filter**

1. Install the TRD air filter.
  -  i. Insert the TRD air filter into the air filter housing lid with the deep side of the filter into the housing base.
  -  ii. Engage the two lid tabs closet to the engine and the two lid clips to secure the housing assembly. (Fig. 2, Fig. 3)
-  2. Use a lint free cloth and a Toyota approved cleaner such as 3M Prep Solvent 70 or similar to clean the air filter housing lid. (See Fig.3 for area)
-  3. Use a lint free cloth and water to clean the same area as in Step 2 above.
-  4. Apply TRD air filter warning label to area pre-cleaned from the steps above. (Fig. 3)



**E. Post Installation**

1. Remove blankets from front fender and grille area.



Section III – Functional Verifications

Check: \_\_\_\_\_

Look For: \_\_\_\_\_



Air Filter Housing Lid

- Re-usable air filter warning label
- Air leaks/gaps