



Southeast Toyota Distributors, LLC Accessory Installation Instructions

2019 Tundra LED Illumination Package (Interior & Exterior)

Year & Model:	2019 Tundra
Part Number:	00016-00069
Accessory Code:	LL1000
PIO / DIO:	PIO / DIO
Business Partner:	L28

Conflicts

Vehicles with factory option code BZ. (Option Code BZ = Work Truck Package, which adds durable vinyl seating & flooring & deletes wireless door lock feature.)

General Applicability

Fits all 2019 models vehicles without factory option code BZ. (Option Code BZ = Work Truck Package, which adds durable vinyl seating & flooring & deletes wireless door lock feature.)

Additional Items Required For Installation

Item#	Description:
1.	N/A

Sequence of Application

Item#	Accessory:
1.	N/A

SPECIAL NOTE: Installation Sequences

After TMS & Safety mandated preparatory steps have been taken, the installation sequence is the suggested method for completing the accessory installation. In some instances the suggested sequence is written for one associate to install & in others the sequence is given as part of a team accessory installation. Unless otherwise stated in the document, the associates may perform the installation steps in any order to make the installation as efficient as possible while maintaining consistent quality.

Recommended Tool

Safety Items	
Glasses	
Installation Tools	
Phillip Screwdriver	
Trim Removal Tool	
Pliers	Rivet Gun
Drill	Torque Wrench
11/64" Drill Bit	3mm Allen Wrench
7/16" Drill Bit	Fish Tape
7 & 10mm Socket/Ratchet	Utility Knife
Special Chemicals	
VDC Approved Sealant	

Legend

	STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.
	OPERATOR SAFETY: Use caution to avoid risk of injury.
	CAUTION: A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.
	TOOLS & EQUIPMENT: Used in Figures calls out the specific tools and equipment recommended for this process.
	REVISION MARK: This mark highlights a change in installation with respect to previous issue.
	SAFETY TORQUE: This mark indicates that torque is related to safety.

TOYOTA TUNDRA LED Illumination Package (Interior & Exterior)

Table of Contents

I.	Preparation.....	1-5
a.)	Table of Contents.....	2
b.)	Kit/Hardware Bag Contents.....	3
c.)	Parts for Installation.....	4
d.)	Service & Warranty Information.....	5
II.	Procedures	
a.)	Vehicle Preparation & Assembly Process.....	6-15
III.	Accessory Function Check.....	16
IV.	Block Diagram & Connectors.....	17-19
V.	Blank Page	20
VI.	Warranty Statement.....	21-22

Kit/Hardware Bag Contents:

Item #	Quantity	Description
1.	4	Puddle Lights and Harnesses
2.	1	Control Module
3.	1	Power Harness
4.	1	Hardware Bag
5.	2	Foot-well Lights
6.	1	Foot-well Harness
7.	4	Mounting Brackets
8.	15	Wire Ties
9.	4	Foil Tape
10.	5	Foam Tape
11.	14	Plastic Rivets
12.	3	Red T-Taps
13.	3	Black T-Tap
14.	1	Blue T-Tap
15.	8	Mounting Bracket Bolts
16.	8	Mounting Bracket Nuts

Parts for Installation:


Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, re-checking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Item	Quantity	Description
1.	4	Puddle Lights and Harnesses
(a)	1	LF (4.9') Puddle Light
(b)	1	LR (7.8') Puddle Light
(c)	1	RF (10.8') Puddle Light
(d)	1	RR (13.8') Puddle Light
2.	1	Control Module
3.	1	Power Harness
4.	1	Foot-well Harness
5.	2	Foot-well Lights
6.	4	Puddle Light Mounting Brackets
7.	1	Hardware Bag



TOYOTA TUNDRA LED Illumination Package (Interior & Exterior)

Service & Warranty Information:

	Parts information		Warranty Information	
	Part Number	Description	Warranty Time	Labor Op. Code
NA	00016-00069	LED Illumination Package (Int & Ext) KIT	NA	NA
A	00016-00064-01	Power harness	0.3	AIP011
B	00016-00064-02	Foot well light harness	0.4	AIP021
C	00016-00064-03	Foot well LED light pod	0.2	AIP031
D	00016-00064-04	Puddle light control module	0.3	AIP041
Not Shown	00016-00064-09	Trunk LED <i>(NOTE: if equipped)</i>	0.2	AIP091
E	00016-00064-05	Left Front puddle light and harness	1.3	AIP051
F	00016-00064-06	Left Rear puddle light and harness	1.3	AIP061
G	00016-00064-07	Right Front puddle light and harness	1.3	AIP071
H	00016-00064-08	Right Rear puddle light and harness	1.3	AIP081

Note: Use Combo codes if replacing more than one puddle light. A for additional 0.3 per light. A- adds 0.3 for two lights, AA- adds 0.6 for three lights, AAA- adds 0.9 for three lights

Labor times include consideration for diagnosis and Administration time

If you are a dealer located outside of the Southeast Region, please contact the SET Accessory Warranty Department at (888) 851-2722 or email Accessory.Warranty@SETToyota.com for claim payment instructions.

Image:



Vehicle Preparation & Assembly Process:



Figure 1




Figure 2




Figure 3

DISCONNECT THE NEGATIVE:

1. **BATTERY CABLE FOR 90 SECONDS BEFORE BEGINNING INSTALLATION, TO AVOID UNINTENDED AIRBAG DEPLOYMENT. NOTE AND RECORD ANY ANTI- THEFT RADIO CODES PRIOR TO DISCONNECTING.**

2. Mark and drill locations for the rear light pod brackets using 11/64" drill bit. These should be centered in line with the 3rd grommet from the rear for both C & D cabs. Figure 1.

NOTE: Flip brackets to the outside of the pinch weld and hold flush to the bottom to mark the drill locations.

-  3. Mark and drill locations for the front light pod brackets using 11/64" drill bit. They should be centered in line with the 3rd grommet from the front, for both C & D Cabs. Figure 2.

NOTE: Apply VPC approved sealant to all pinch weld holes before mounting brackets.

4. Install all 4 mounting brackets using included bracket hardware. Brackets should be in-board of pinch weld, with bolts being fed through the pinch weld then the bracket. Figure 3.
5. Mount appropriate light in corresponding location (RR-Right Rear) securing in place with plastic rivets.

NOTE: Arrow on puddle light lens must face out, away from bracket tabs.



Figure 4

6. Remove left and right front drain plugs. Figure 4.




Figure 5

7. Remove Front Door Scuff Plate (LH)

- (a) Detach the 6 claws and the 3 clips and remove the front door scuff plate, LH. Figure 5.

8. Remove the Cowl Side Trim Board LH. Figure 6.




Figure 6

- (a) Remove the nut.

- (b) Detach the 2 clips and remove the cowl side trim board LH.

- (c) Repeat for RH side.



Figure 7a



Figure 7b



Figure 8



Figure 9

9. Route rear harnesses forward along frame rails, wire tying to factory harness on passenger side & e-brake cable on driver side. Secure front harnesses in the same fashion. Figures 7a. & 7b.

10. Using a sharp blade, cut an 'X' in the middle of each drain plug, in order to route the harnesses through and into the vehicle.

11. Lift carpet to gain access to the drain holes and route puddle light harnesses up and into the vehicle.

12. Re-install drain plugs, with both front & rear harnesses threaded through the plugs. Figure 8.

13. Seal harnesses to drain plugs using VPC approved sealant. Make sure to work sealant completely around wires for a water tight seal.

14. Remove foam foot-board with phillip head screw driver & route passenger harnesses towards the center console, taping in place using foam tape. Figure 9.



Figure 10



Figure 11




Figure 12

15. Fish harnesses over to driver side foot-well.

16. Route driver side harnesses under foam foot-board towards kick panel, figure 10. Tape in place, using foam tape. Figure 11.

17. Route Instrument Panel Lower Finish Panel Sub-Assembly, LH. Figure 12.

- (a) Operate the tilt lever to fully extend and raise the steering column.
- (b) Apply protective tape as shown in the illustration.
- (c) Remove the 2 bolts.
- (d) Detach the 9 clips, claws and remove the lower instrument panel finish panel sub-assembly, LH
- (e) Disconnect each connector.




Figure 13a




Figure 13b



Figure 13c




Figure 14

(f) Detach the 3 hooks and disconnect the hood lock control lever from the lower instrument panel sub-assembly LH.

(g) Pull and slide the hood lock control cable, rotate the hood lock control cable and then disconnect the hood lock control cable from the hood lock control lever. Figure 13b.

Note: Place red hang tag on instrument panel sub assembly OR hood release cable when removing hood latch cable from hood latch release lever. See Figure 13c.

Red Tag required for PIO only.

Tag is not part of the kit contents.

18. Remove the No. 2 Instrument Panel Under Cover Sub-Assembly.

(a) Detach the clip, 4 claws & 2 guides and remove the No. 2 instrument panel under cover sub-assembly. Figure 14.




Figure 15



Figure 16





Figure 17

19.  Align foot-well light with the flat side facing towards the seats. Using an 11/64" drill bit drill mounting holes. Attach using included rivets.

20. Make a 1/2" x 1/2" notch in the middle of the driver side lower finish panel. Figure 15.

21. Mark where passenger side foot-well light will be mounted, 1/2" from front rib and 1/2" from right side rib. Figure 16.

22.  Drill a 7/16" hole where the foot-well light will be mounted.

23.  Align light with the connector through the hole and flat side facing the seats. Using an 11/64" drill bit, drill mounting holes. Mount light using included rivets.

24. Route the long side of the foot-well power harness from the driver side to the passenger side, securing to the blower motor factory harness. Figure 17.

25. Connect foot-well light and reinstall the No. 2 instrument panel under cover sub-assembly.



Figure 18a




Figure 18b

26. Using a Red T-tap, connect the **Red** wire from the puddle light power harness to the **Blue** wire of the factory Foot Light harness. Figures 18a and 18b.

27. Using a Red T-tap, connect the **Black** wire of the puddle light power harness to the **Brown** wire of the factory Foot Light harness. Figures 18a and 18b.

28. Connect the **Red** wire from the foot-well harness to the **Red** wire from the puddle light power harness. Connect the **White** wire from the foot-well harness to the **White** wire from the puddle light harness.



Figure 19

29. Locate the connect on the front of the dash panel. Figure 19.

30. Using a Red T-Tap, connect the Black wire to the White-Black wire in Pin 5 of the **J104** headlight leveling switch. Figures 20 & 20b.



Figure 20a

31. Using a Red T-Tap, connect the Yellow wire to the Light Green wire in Pin 1 of the **J132** Interior dome light switch. Figures 20a-20c.




Figure 20b





Figure 20c






Figure 21

32. Secure all passenger side harnesses behind the driver side lower instrument panel routing above air bag assembly wire tying to the crash bar right of the steering and to the factory harness below the steering wheel. Figure 21.



Figure 22

33. Route additional foot-well connector to driver side foot-well light, wire tying to the crash bar above the knee the knee air bag mount. Figure 22.




Figure 23

34. Connect all harnesses to the control module and mount to the factory harnesses in the driver side kick panel. Figure 23.

35. Connect driver side foot-well lamp and reinstall No. 1 instrument panel under cover subassembly.



36. Reinstall all trim panels in the order of removal taking special care to make sure all harnesses and wiring are properly secured. Make sure harnesses are not pinched or bound by trim pieces.





37. Reconnect negative battery cable and torque to 48in lbs.

38. (DIO, Only) Print Warranty Statement & place in glove box.

CHECKLIST - THESE POINTS MUST BE CHECKED TO ENSURE A QUALITY INSTALLATION

ACCESSORY FUNCTION CHECK

CHECK:

-  Test for Full Light condition
-  Test for Low Light condition

LOOK FOR:

Close all doors and lock vehicle, do foot-well and puddle lights go out?
 Unlock vehicle, do foot-well lights come on full brightness? Do puddle lights come on?
 Start vehicle, do puddle lights go out?
 Do the foot-well lights shut off?
 Turn on headlights, do foot-well lights come on in dim mode?

VEHICLE FUNCTION:

-  Ignition
-  SRS warning light
-  Hood Latch
-  Headlight leveling system
-  Warranty Statement

VEHICLE FUNCTION DETAIL :

Verify that vehicle will crank.


Close hood and operate hood latch mechanism to assure proper operation.

Turn headlights on and operate headlight leveling system. Check that both headlights operate up and down through their full range of movement simultaneously.

Confirm SRS warning light illuminates for approximately 6 seconds with the ignition on, and then goes out.


Place Warranty in glove box, DIO Only.

Block Diagram
TUNDRA
LED Lighting Package



**Connector C-1 thru C-4**

Pin	Wire Color	Test Reference	Proper Orientation
1	Black	Pin 1 to Ground	Exterior LEDs (-)
2	Red	Pin 2 to Ground	Exterior LED (+)

**Connector C5**

Pin	Wire Color	Test Reference	Proper Operation
1	Black	Pin 1 to Ground	Approximately 0 VDC
2	Red	Pin 2 to Ground	Approximately 0 VDC when Dome Light is ON +12 VDC when Dome Light is OFF
3	White	Pin 3 to Ground	Approximately 0 VDC (when disconnected from control module)
4	Red	Pin 4 to Ground	Approximately 0 VDC (when disconnected from control module)

Connector C6

Pin	Wire Color	Test Reference	Proper Operation
1		Pin 1 to Ground	Approximately 0 VDC when Dome Light is ON +12 VDC when Dome Light is OFF

Connector C7

Pin	Wire Color	Test Reference	Proper Operation
1			+12 VDC

Connector C8 & C9

Pin	Wire Color	Test Reference	Proper Operation
1	Red	Pin 1 to Ground	+12 VDC
2	Black	Pin 2 to Ground	Approximately 0 VDC
3	White	Pin 3 to Ground	Approximately 0 VDC when Dome Light is ON +12 VDC when Dome Light is OFF
4	Yellow	Pin 4 to Ground	Approximately 0 VDC ignition switch OFF +12 VDC when ignition ON

Connector C10

Pin	Wire Color	Test Reference	Proper Operation
1	White	Pin 1 to Ground	Approximately 0 VDC when Dome Light is ON +12 VDC when Dome Light is OFF

Connector C11

Pin	Wire Color	Test Reference	Proper Operation
1	Red	Pin 1 to Ground	+12 VDC

Connector C12

Pin	Wire Color	Test Reference	Proper Operation
1	Yellow	Pin 1 to Ground	Approximately 0 VDC ignition switch OFF +12 VDC when ignition ON

Connector C13

Pin	Wire Color	Test Reference	Proper Operation
1	Black	Pin 1 to Ground	Approximately 0 VDC



LIMITED WARRANTY – SOUTHEAST TOYOTA

SOUTHEAST TOYOTA DISTRIBUTORS, LLC ("we," "our" and "us") provides the following limited warranty on our accessories, excluding tires, ("Accessories" or "Accessory") installed on a Toyota. This limited warranty is not provided by and does not bind or provide benefit to the vehicle dealer, the manufacturer, or Toyota Motor Sales, U.S.A., Inc. This limited warranty does not apply to tires; please consult the tire manufacturer and/or its materials accompanying the vehicle for any warranty terms concerning tires. This limited warranty also does not apply to ToyoGuard Exterior Paint Sealant and ToyoGuard Interior Protector; please consult the ToyoGuard Limited Warranty Certificate for the warranty terms concerning those products.

SCOPE OF LIMITED WARRANTY:

A. Protection:

- i. **Accessories Installed by Southeast Toyota Distributors, LLC on a new Toyota vehicle.** We warrant that, for a period of 36 months or 36,000 miles, whichever occurs first, we will repair or replace (includes labor), free of charge, any defect in such an Accessory due to faulty material or workmanship, or, at our option, provide a full refund of the purchase price of the Accessory. The warranty period begins on the vehicle's In-Service Date, which is the first date the new vehicle is either delivered to an ultimate purchaser, leased, or used as a company car or demonstrator. Accessories installed by Southeast Toyota Distributors, LLC are identified on the vehicle's window sticker (Monroney Label).
- ii. **Accessories Installed by a Toyota Dealer on a Toyota vehicle.** We warrant that, for 12 months, regardless of mileage, from the date such an Accessory was installed on the vehicle or the remainder of the Toyota new vehicle warranty, whichever is longer, we will repair or replace (includes labor), free of charge, any defect in the Accessory due to faulty material or workmanship, or, at our option, provide a full refund of the purchase price of the Accessory. For a new vehicle, the warranty period begins on the vehicle's In-Service Date, which is the first date the new vehicle is either delivered to an ultimate purchaser, leased, or used as a company car or demonstrator.
- iii. **Accessories purchased from a Toyota Dealer but not installed by the Toyota Dealer.** We warrant that, for a period of 12 months, regardless of mileage, from the date the accessory was purchased, we will repair or replace (does not include labor), free of charge, any defect in the Accessory due to faulty material or workmanship, or, at our option, provide a full refund of the purchase price of the Accessory.

B. Limitation of Warranty. This limited warranty does not apply to, and we will not repair, replace, or reimburse you for: (1) wheel balancing and wheel alignments, except for one wheel balancing or alignment during the first 12 months or 12,000 miles, whichever occurs first, from the vehicle's In-Service Date, as defined above, (2) abrasions or dents, whatever their cause, and any failure or damage resulting directly or indirectly from accidents, collisions, impacts from foreign objects, fire, theft, larceny, explosion, malicious mischief, vandalism, civil commotion, riots, war, or any other similar causes, (3) any failure or damage resulting directly or indirectly from lightning, windstorms, hail, water, floods, subfreezing temperatures, airborne chemicals, tree sap, dust, salt, and any other environmental conditions or similar causes, (4) any failure or damage caused by: (a) a failure of any part, other than the Accessory, (b) any misuse, abuse, improper towing, negligence or lack of maintenance of the vehicle or Accessory, (c) the alteration, modification or repair of the Accessory by anyone other than persons expressly authorized by us to perform such alteration, modification or repair, or (d) the use of the vehicle for commercial purposes, competitive driving or racing, (5) any failure or damage, if the Accessory has not been installed according to instructions, (6) any failure or damage occurring outside of Canada, the United States of America, its territories or possessions, (7) except to the extent required by the state whose laws govern this limited warranty, any consequential, secondary, or unreasonable costs that may be suffered as a result of the need to repair or replace the Accessory, including without limitation any loss of use of the vehicle, road service, towing, storage charges, inconvenience, loss of wages and/or income, additional expense incurred, loss of transportation, rental car expense, or any derivative damage to persons or things other than the Accessory, including other parts of the vehicle, or (8) liability for damage to property or for injury to or death of any person, arising out of the operation, maintenance or use of your vehicle whether or not related to the covered Accessory.

C. Exclusive Remedy. If there is a valid claim under this limited warranty for a defect due to faulty material or workmanship in the Accessory, we will, at our option, either: (i) repair, (ii) replace or (iii) provide a full refund of the purchase price of the Accessory. We have no other obligations under this limited warranty. Refunds will be made to the vehicle owner. If the vehicle is leased, the refund will be made to the leasing company.

HOW TO MAKE A CLAIM: In the event of a warranty claim, please contact the nearest Toyota dealer to arrange for repairs. The dealership must receive our prior authorization before making repairs covered by this limited warranty. The dealer will contact Southeast Toyota Distributors, LLC at 1-888-851-2722, select option #5 (Warranty Department), then option #4 (Repairs), for instructions on processing a warranty claim, if they are not already familiar with the process. If you have any questions or concerns regarding repairs covered by this limited warranty, please contact our **Customer Assistance Hotline at 1-800-301-6859**.

OUR DISPUTE RESOLUTION PROGRAM: Your satisfaction is our highest priority. In keeping with that focus, in the event that an issue arises related to this Limited Warranty, we invite you to call our Customer Assistance Hotline at 1-800-301-6859 to discuss it. In most cases, we expect that a satisfactory resolution of your issue can be reached through engagement with that Department. If our Customer Loyalty Department is unable to resolve your issue to your satisfaction, we offer a dispute resolution program administered by the National Center for Dispute Settlement (NCDS) ("the Program"). The purpose of the Program is to resolve disputes in an informal setting before an impartial arbitrator. The Program is free of charge to you (although you must bear the cost of any expert witness or attorney you elect to employ). You are required to complete the Program before exercising rights or seeking remedies under the federal Magnuson-Moss Warranty Act, 15 U.S.C. § 2301 et seq. ("the Act"). If you choose to seek remedies that are not created by the Act, you are not required to use the Program before pursuing such remedies – although the Program is still available to you to resolve the dispute. When utilizing the Program, you will need to provide (a) the vehicle identification number of your vehicle, (b) the identity of your selling and servicing dealerships, (c) the mileage on your vehicle at relevant times, (d) the date and nature of any relevant repairs, (e) legible copies of repair orders and other relevant documents, (f) a summary of the unresolved issue and the requested action, and (g) your contact information. In most cases, the dispute resolution process under the Program will be completed within forty (40) days of your submission of your request and will consist of steps such as an initial eligibility determination, an opportunity for you and us to submit information in writing relating to your claim, an oral hearing, and a decision from the arbitrator. A decision will be binding on you only if you choose to accept it. You may submit a request to NCDS by telephone at their toll free number: (877)-276-8848 or in writing at P.O. Box 463196, Mt. Clemens, MI 48046. You may obtain additional information regarding the Program at www.ncdsusa.org. In the event that the NCDS does not exist or no longer handles disputes for us at the time that you seek to submit a request, you may contact our **Customer Assistance Hotline at 1-800-301-6859** to obtain current information about our dispute resolution programs.

GENERAL LIMITATION OF WARRANTY: THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES OR LIABILITIES. IN NO EVENT SHALL WE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. SOME STATES DO NOT ALLOW THE EXCLUSIONS OR LIMITATIONS OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE INFORMATION OR EXCLUSION MAY NOT APPLY. NO EXPRESS WARRANTY OF FITNESS OR MERCHANTABILITY IS GRANTED BY THIS LIMITED WARRANTY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THOSE DESCRIBED IN THIS DOCUMENT. ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, WHICH MAY BE APPLICABLE BY OPERATION OF LAW SHALL BE LIMITED TO THE PERIOD OF THIS WRITTEN LIMITED WARRANTY. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY. THIS LIMITED WARRANTY PROVIDES SPECIFIC LEGAL RIGHTS, AND THERE MAY BE OTHER RIGHTS WHICH VARY FROM STATE TO STATE. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, MUST BE BROUGHT WITHIN A PERIOD NOT EXCEEDING 12 MONTHS AFTER EXPIRATION OF THIS LIMITED WARRANTY. THE REMEDIES SPECIFIED HEREIN AND THOSE SPECIFIED BY APPLICABLE LAW ARE THE ONLY REMEDIES AVAILABLE. WE ASSUME NO OTHER OBLIGATION OR RESPONSIBILITY WITH REGARD TO THE ACCESSORY. WE NEITHER ASSUME, NOR AUTHORIZE ANYONE TO ASSUME FOR US, ANY ADDITIONAL LIABILITY IN CONNECTION HERewith.

GENERAL: This limited warranty describes the complete and exclusive rights that result from the purchase of Accessories. No oral representations or statements may be relied upon. This limited warranty may not be amended or modified, and additional rights may not be granted, unless in a written statement signed by one of our officers. This limited warranty shall be governed by the laws of the state where the vehicle is purchased, excluding laws concerning conflicts of law. We may delegate the performance of our duties and obligations and assign our rights and benefits hereunder. For inquiries regarding this limited warranty, we can be contacted directly at **Customer Assistance Hotline at 1-800-301-6859**, or by mail to: **Southeast Toyota Distributors, LLC, Attention: Customer Loyalty Department, 100 Jim Moran Boulevard, Deerfield Beach, Florida 33442.**