

Part Number: PT769-08110-FR
PT769-08110-RR**NOTE:** Part number of this accessory may not be the same as the part number shown.**Kit Contents**

Item #	Quantity Req'd.	Description
1	1	Front Passenger Side Mudguard
2	1	Front Driver Side Mudguard
3	1	Rear Passenger Side Mudguard
4	1	Rear Driver Side Mudguard
5	2	Hardware Kit
6	1	Instruction Sheet

Hardware Bag Contents

Item #	Quantity Req'd.	Description
1	6	#10 x 15 mm Screws (short)
2	4	#10 x 19 mm Screws (long)
3	6	#10 Spring Clips (short)
4	2	#10 Spring Clips (long)

Additional Items Required For Installation

Item #	Quantity Req'd.	Description
1		
2		
3		

Conflicts

Note: Ground effects

Recommended Tools

Personal & Vehicle Protection	Notes
None	
Special Tools	Notes
None	
Installation Tools	Notes
Screwdriver	Phillips #2 & 3, Slot
Drill	Standard/Right Angle
Drill Bits	2.5 mm (3/32")
	6 mm (1/4")
Clean Cloth/Rag	
Special Chemicals	Notes
Cleaner	3M™ Prep Solvent-70
Alcohol/Water Mixture	

General Applicability

--

Recommended Sequence of Application

Item #	Accessory
1	
2	
3	

*Mandatory




Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Req'd.	Description
1		
2		
3		

Legend**STOP:** Damage to the vehicle may occur. Do not proceed until process has been complied with.**OPERATOR SAFETY:** Use caution to avoid risk of injury.**CAUTION:** A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.**TOOLS & EQUIPMENT:** Used in Figures calls out the specific tools and equipment recommended for this process.**REVISION MARK:** This mark highlights a change in installation with respect to previous issue.**SAFETY TORQUE:** This mark indicates that torque is related to safety.

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle.

The installation of this accessory must follow all instructions and use supplied hardware to ensure an approved quality installation.



1. Clean Front Mounting Area



(a) Clean and degrease front body panel use 3M™ Prep Solvent – 70 or alcohol and water mixture.

(b) When cleaning with 3M™ Prep Solvent-70 follow the manufacturer's directions. Do not allow cleaner to air dry.

2. Removal of Existing Screws



(a) Remove existing screws, locations A and B. DO NOT DISCARD (Fig 2-1)

3. Installation of Front Mudguard



(a) Mount mudguard on body panel and reinstall existing screws in location A and B while holding part up and into body panel. (Fig. 3-1)

4. Installation of Lower Mount Tab






(a) While holding part in position, drill 2.5mm (3/32") pilot hole in location C. (Fig 4-1)



(b) Install supplied 19mm (long) self tapping screw into location C while holding part into body panel. (Fig. 4-1)

(c) Repeat procedure for other side

NOTE: For easier accessibility wheels can be removed or use a right angled drill.



5. Clean Rear Mounting Area



- Clean and degrease rear body panel where mudguard is to be located with a clean, dry lint free cloth and 3M™ Prep Solvent-70 or alcohol and water mixture.
- When cleaning with 3M™ Prep Solvent-70 follow the manufacturer's directions. Do not allow cleaner to air dry.


6. Mount Hole Preparation

- Remove existing push pin location D drivers side and discard. (Fig 6.1)
- Mount mudguard, using part as a template, drill 6mm (1/4 inch) holes in panel edge at locations A, B and C while holding part up and into body panel. Fig. (6-2).
- Passengers side will require a hole to be drilled in location D mount tab, while holding part up and into body panel.
- IMPORTANT:** Make sure mudguard is seated in the correct position before drilling. If holes are too low, gapping will occur.

Installation of Spring Clips



- Install supplied spring clips (small) over panel edge holes location A, B and C with turned up edge on inside of panel. (Fig. 7-1)
- Pull rear liner down and install supplied spring clip (long) over panel edge hole location D with turned up edge on inside of panel. (Fig 7-1)




7. Installation of Mudguards



- (a) Mount mudguard and install supplied screws 15mm (short) in locations A, B and C. Tighten screws while holding mudguard up and into body panel.

(Fig 8 -1)



- (b) While holding mudguard up and into body panel install supplied screw 19mm (long) screw in location D, drivers' side. (Fig 8-2)
- (c) For passenger side hold mudguard up and into body panel install supplied 19mm screw (long) and #10 spring clip (long) as a nut in location D. (Fig 8-2)

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:

Accessory Function Checks

☐ Gaps between mudguards and body side

Look For:

Excessive gaps greater than 1.0 mm.